

This standard operating procedure supersedes all previous procedures related to this topic.


PURPOSE The purpose of this procedure is to provide the correct and safest method for the installing of Steel Guide Posts.

SCOPE The scope of work covers Pnuematically installing - Steel Guide Posts into the ground using the Roadside Products recommended installation tools .

BEFORE YOU BEGIN The approved equipment for installing this type of post is the FPD1800 – Pnuematic Driver. *Refer to Diagrams*

SAFETY EQUIPMENT Roadside Products recommends the use of Australian Standard approved personal protective equipment when installing our products, i.e.


While Installing Posts on the roadside, Roadside Products recommends facing the oncoming traffic and the following instructions are based on that position.

PPE	(✓)	
Eye protection	<input checked="" type="checkbox"/>	
Hearing protection	<input checked="" type="checkbox"/>	
Gloves	<input checked="" type="checkbox"/>	
Covered footwear steel cap	<input checked="" type="checkbox"/>	
High visual clothing	<input checked="" type="checkbox"/>	

FPD1800
 Pnuematic Driver



FPD1907
 W shape driving cap



Step 1



Lay Pnuematic Driver FPD1702 on ground in line with installation position.

Step 2



Fit W shape driving cap FPD to the steel post

Step 3



Insert steel post and cap into the driving slot in the Pnuematic Driver,

Step 4



slowly lift the Pnuematic Driver and post into position

Step 5



Ensure the post is straight and begin installation.

Step 6



Ensure the post is installed to the depth mark.

Step 7



Remove Pnuematic Driver from the post.

Step 8



Remove W shape cap from the post.

Step 9



Fit safety cap

Step 10



Installation complete