


This standard operating procedure supersedes all previous procedures related to this topic.

PURPOSE The purpose of this procedure is to provide the correct and safest method for the installing and removing Flexi 360 Pro Series Guide Posts.

SCOPE The scope of work covers manually installing - Flexi 360 Pro Series Guide Posts into the ground using the Roadside Products recommended installation tools .

BEFORE YOU BEGIN The approved equipment for installing this type of post is the FPD2706 – Jackhammer attachment. *Refer to Diagrams*

SAFETY EQUIPMENT Roadside Products recommends the use of Australian Standard approved personal protective equipment when installing our products, i.e.

PPE	(✓)	
Eye protection	<input type="checkbox"/>	
Hearing protection	<input type="checkbox"/>	
Gloves	<input type="checkbox"/>	
Covered footwear steel cap	<input type="checkbox"/>	
High visual clothing	<input type="checkbox"/>	

FPD2706



INSTALLATION PROCEDURE



STEP 1



Slide Flexi 360 Pro through handle of jackhammer

STEP 2



Locate attachment into slot of anchor

STEP 3



Holding the jackhammer and Flexi Post together, stand upright, stand in position, ensure post is vertical before starting to drive

STEP 4



Commence driving, ensure post is vertical

STEP 5



Drive in until the top of the anchor is at ground level

STEP 6



Slide the jackhammer up over the top of the post

INSTALLATION COMPLETE



The Flexi 360 Pro guide posts are not meant to be removed easily. To remove loosen the soil around the anchor and using a steel bar lever upwards from under the flexible joint

For Installation Procedure for the Dura-FlexPVC Pro and uPVC Pro Delineator Posts Systems please follow the same procedure as shown for the Flexi360 Pro 1 – Part Installation procedure.