

This standard operating procedure supersedes all previous procedures related to this topic.


**PURPOSE** The purpose of this procedure is to provide the correct and safest method for the installing Flexi360 Pro Series Guide Posts.

**SCOPE** The scope of work covers manually installing - Flexi360 Pro Series Guide Posts into the ground using the Roadside Products recommended installation tools .

**BEFORE YOU BEGIN** The approved equipment for installing this type of post is the FPD1702 – Pro Series Manual driver. *Refer to Diagrams*

**SAFETY EQUIPMENT** Roadside Products recommends the use of Australian Standard approved personal protective equipment when installing our products, i.e.

**While Installing Posts on the roadside, Roadside Products recommends facing the oncoming traffic and the following instructions are based on that position.**

PPE	(✓)	
Eye protection	<input checked="" type="checkbox"/>	
Hearing protection	<input checked="" type="checkbox"/>	
Gloves	<input checked="" type="checkbox"/>	
Covered footwear steel cap	<input checked="" type="checkbox"/>	
High visual clothing	<input checked="" type="checkbox"/>	

**FPD1702 – PRO SERIES Manual Driver**



**STEP 1**

Lay Driver FPD1702 on ground in line with installation position. and manoeuvre so slot in driveable anchor aligns with slot in manual driver point.

**STEP 2**

Holding both the post and driver, stand up into installation position – ensure the slot in the driver point is connected firmly into the slot in the anchor, this connection allows for steering the post during the driving process

**STEP 3**

Remove slide retaining clip from driver body

**STEP 4**

Holding both the post and manual driver, slowly lift the driver body with one hand and slide down to start driving, repeat until the post anchor is supporting the post

**STEP 5**

Now using two hands, one on each of the driver handles, drive the post.

**STEP 6**

Stop during the driving process to check that the post is being driven vertically

**STEP 7**

The top of the metal collar should be at or just below ground level –

**STEP 8**

Re fit the slide retaining clip and remove driver off anchor

**STEP 9**

Installation complete

**\*Ensure Dura-FlexPVC guide posts are installed to depth mark indicator \***